7 in 1 Fitness Starter Kit

USER'S GUIDE

for Wii Fit™

dreamGEAR®
www.dreamgear.net

PACKAGE CONTENTS:

- NeoSleeve
- Mini Massager
- Yoga Mat
- Yoga Mat Sling
- Rechargeable Battery Pack
- Wii Remote and Nunchuk Holsters
- Fitness Socks
- User's Guide/Warranty Card
- Registration Card

USING THE NEOSLEEVE:

1. Place the NeoSleeve upside down on any flat surface.
2. Place the Wii Balance Board upside down directly on top of the NeoSleeve, aligning the power button hole with the power button on the Wii Balance Board.
3. One at a time, gently stretch each corner of the NeoSleeve over its corresponding balance sensor on the bottom of the Wii Balance Board. Be careful not to rip the NeoSleeve.
4. Carefully smooth out any wrinkles by pulling gently on the outer seam of each corner.

USING THE MINI MASSAGER:

1. Remove the battery cover on the top of the Mini Massager by pushing down on the top and turning in a counter-clockwise direction.
2. Insert 3 "AAA" batteries (sold seperately).
3. Replace the battery cover and turn clockwise to lock.
4. Massaging action is activated automatically when pressure is applied to the top of the Mini Massager.

USING THE WII REMOTE AND NUNCHUK HOLSTERS:

1. Attach the Wii Remote and Nunchuk Holsters to your belt, pants or shorts using the clips on the back.
2. Place the Wii Remote and Nunchuk into the Holsters when not in use.

USING THE YOGA MAT:

1. Unroll the Yoga Mat and place it on any flat surface.
2. For Wii Fit workouts, you may place your Wii Balance Board on top of the Yoga Mat.
3. To ensure the long life of your Yoga Mat, clean when necessary with a damp cloth and store in a cool, dry location.

USING THE YOGA MAT SLING:

1. Roll up the Yoga Mat tightly.
2. Wrap the elastic loops around each end of the rolled mat.

USING THE RECHARGEABLE BATTERY PACK:

1. Remove the original battery cover and any other batteries from your Wii Balance Board.
2. Insert the Rechargeable Battery Pack into the Wii Balance Board battery compartment by inserting the two locking tabs into the matching slots and pushing down. The Rechargeable Battery Pack will click into place securely.
3. To charge, plug the mini-USB end of the charging cable into the Rechargeable Battery Pack.
4. Plug the standard USB end of the charging cable into any available USB port on the Wii console or any other powered USB port.
4. The green LED light indicates that the Rechargeable Battery Pack is charging.
5. The red LED light indicates that the charge cycle is complete and the Rechargeable Battery Pack is ready for use.

dreamGEAR®
www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net